

Work Order ID 60728

Wednesday, July 21, 2010 12:48:50 PM



Page 1

Item ID: D350-567-025

Accept



Setup Start



Revision ID:

Item Name: Floor Window Installation, Large

Stop



Start Date: 7/21/2010 Start Qty: 2.00



Cust Item ID:

Required Date: 7/21/2010 Req'd Qty: 2.00



Customer:

Reference:

Approvals: Process Plan: *mk*

Date: *0-7-21*

Tooling:

Date:

QC:

Date:

SPC (Y/N):

Date:

Run Start



Stop



Sequence ID/
Work Center ID

Operation
Description

Set Up/
Run Hours

Tool ID

Tool #

Plan
Code

Accept
Qty

Reject
Qty

Reject
Number

Insp.
Stamp

Draw Nbr

Revision Nbr

N/A

Rev D

100

0.00



DOCUMENT CONTROL

DC

Memo

0.00

Document Control

Copy bluefile and create labels & DT8439 per PPP D350-567-025 CHG002

S. Soler

for BG 10/07/21

110

0.00



Packaging

Packaging

Memo

0.00

Packaging

S Pick Packing KitC ***ENSURE DT 8439 TEMPLATE IS INCLUDED***

CPW 7/21 @

120

0.00



QC4- 100% Inspect kits for completeness

QC

Memo

0.00

Quality Control

S. Soler 7/21

@

W/O:		WORK ORDER CHANGES						
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector	

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Work Order ID 60728

Wednesday, July 21, 2010 12:48:50 PM



Page 2

Item ID: D350-567-025

Accept



Setup Start



Revision ID:

Item Name: Floor Window Installation, Large

Stop



Start Date: 7/21/2010 Start Qty: 2.00



Cust Item ID:

Required Date: 7/21/2010 Req'd Qty: 2.00

Customer:

Reference:

Approvals: Process Plan: _____ Date: _____ Tooling: _____ Date: _____
QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Run Start



Stop



Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp Stamp
130	Packaging	0.00				10.7	22	22	SP
Packaging	Memo	0.00							
Packaging	Identify and pack for shipping as per PPP D350-567-025 <input type="checkbox"/> Location: <u>23</u> <input type="checkbox"/> PPP Rev: <u>C</u> <input type="checkbox"/> *****Ensure DT8439 template is included in kit*****								
140	QC21- Final Inspection - Work Order Release	0.00							
QC	Memo	0.00							
Quality Control									

10/07/23

MF

10-7-22

W/O:		WORK ORDER CHANGES						
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector	

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Picklist Print

Wednesday, July 21, 2010 12:48:49 PM

Page 1

Work Order ID: 60728

Parent Item: D350-567-025

Parent Item Name: Floor Window Installation, Large

Start Date: 7/21/2010

Required Date: 7/21/2010

Start Qty: 2.00

Required Qty: 2.00

Comments: IPP Rev:B Added Cutting Template 05-12-14 JLM
IPP Rev:C 08-10-07 as per revD DD verified by:

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
---------------------------------	------------------------	---------------	-------------	---------------------	------------------	-----------------	--------------------	----------------	-------------	--------------	---------------	----------------	--------

D350-567-023

Manufactured

No

120

Each

1.0000



1

2

60730

14

Replacement Window, Large

Location

Loc Qty

Loc Code

FG023

1

59789

1

120

Each

1.0000



1

2

59789

14

D350-567-031

Manufactured

No

Interior Floor Window (Sliding Door Compatible)

Location

Loc Qty

Loc Code

FG060

1

59680

1

120

Each

0.0000



1

2

59680

14

DT8439

template

01/10/22

W/O:		WORK ORDER CHANGES						
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector	

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

5.0 PARTS LIST

Qty -015	Qty -017	Qty -025	Qty -027	Qty -111	Qty -117	Part Number	Description
X						D350-567-015	FLOOR WINDOW INSTALLATION (SMALL)
	X					D350-567-017	FLOOR WINDOW INSTALLATION (SMALL)
		X				D350-567-025	FLOOR WINDOW INSTALLATION (LARGE)
			X			D350-567-027	FLOOR WINDOW INSTALLATION (LARGE)
				X		D350-567-111	FLOOR WINDOW INSTALLATION (EXTRA LARGE)
					X	D350-567-117	FLOOR WINDOW INSTALLATION (EXTRA LARGE)
1	1					D350-567-013	REPLACEMENT WINDOW KIT (SMALL)
		1	1			D350-567-023	REPLACEMENT WINDOW KIT (LARGE)
				1	1	D350-567-113'	REPLACEMENT WINDOW KIT (EXTRA LARGE)
	1		1	1		D350-567-115	INTERIOR FLOOR WINDOW KIT
1		1			1	D350-567-031	INTERIOR FLOOR WINDOW KIT (SLIDING DOOR COMPATABLE)

Qty -013	Qty -023	Qty -113	Qty -115	Qty -031	Part Number	Description
X					D350-567-013	REPLACEMENT WINDOW KIT (SMALL)
	X				D350-567-023	REPLACEMENT WINDOW KIT (LARGE)
		X			D350-567-113	REPLACEMENT WINDOW KIT (EXTRA LARGE)
			X		D350-567-115	INTERIOR FLOOR WINDOW KIT
				X	D350-567-031	INTERIOR FLOOR WINDOW KIT (SLIDING DOOR COMPATABLE)
1					D2125	REPLACEMENT WINDOW, SMALL
	1				D2942	REPLACEMENT WINDOW, LARGE
		1			D3290-041	REPLACEMENT WINDOW ASSEMBLY, EXTRA LARGE
1					D2126-0600	SEAL
	1				D2463-0750	NEOPRENE SEAL
		1			D2463-0860	NEOPRENE SEAL
	9	12			2600-6	1/4 TURN FASTENER
	9	12			2600-LW	WASHER
	9	12			212-12	RECEPTACLE
	22	21			AN526C832R9	SCREW (OR AN526C832-9, OR MS51957-126)
	44	42			AN960JD8	WASHER
	22	21			MS21042L08	NUT (OR MS21042-08)
	18	24			MS20426AD3-5	RIVET
2 SQ. YD	2 SQ. YD	2 SQ. YD			N/A	9.7oz 7781 'S' GLASS UNIVERSAL WEAVE
				1	D2463-0450	NEOPRENE SEAL
				1	D3210-1	DOUBLER
				1	D3211-1	BRACKET
				1	D3212-1	FLOOR WINDOW
				1	D3213-041	DOOR ASSEMBLY
			1		D3293-1	DOUBLER
			1		D3294-1	BRACKET
			1		D3295-041	FLOOR WINDOW
			1		D3296-041	DOOR ASSEMBLY
			1		D2463-0530	NEOPRENE SEAL
			9	8	AN526C632R12	SCREW (OR AN526C632-12, OR MS51957-32)
			9	8	AN960JD6	WASHER
			9	8	MS21042L06	NUT (OR MS21042-06)
			2	40	MS20470AD4-5	RIVET
			115	90	MS20470AD4-6	RIVET
			15	20	MS20470AD4-7	RIVET